PC software Zetta

spyshop
Ko morate izvedeti

Contact the vendor:

PRIVATE DOO

Trzaska ROUTE 297 1000 LJUBLJANA

Tel: 051 704 555, email: info@spy-shop.com

1. Detailed instructions

Links to download the software:

- PC version http://www.zetta.com.hk/files/software/ZettaWidget_Setup.exe
- Mac version http://www.zetta.com.hk/files/software/Zetta_Widget.dmg

3.1 Basic commissioning software

1. Download the program and install it.
2. Connect the device to a PC and turn on the program.
3. It is now possible to set the time and user mode.

3.1 Time Settings

1. Click on the "Sync Date Time to DVR".
2. After successfully setting the time display "Date Time Updated".
3. It is possible to set a different time - under "Custom Date Time".

3.2 Activating the more detailed settings

1. The program defaults to "Express" mode settings. The neumožňujedetailníSettings individual parameters. Therefore, first go to the menu "Option" and here you select "Custom Mode".
2. Save the settings by clicking on "Save Option".
3. It is also possible to change the language if you meet any of more than AJ.

3.3 Adjustment

1. Video Quality - Quality
2. Resolution - Resolution
3. Frame rate - the number of frames per second
4. Setting light conditions (50 / 60Hz indoors / outdoors - outdoors)
5. Day / Night - Day / night / car
6. Image Orientation - a mirror image can be rotated when the camera is placed on the contrary than usual
7. Timestamp - time display on records
8. Circular Recording - Record in loop
9. File Split Time - set the time after which the recordings have to divide
10. Mic - on / off microphone - ie. in audio recording
11. Power On / Off LED
12. Voice Trigger - sensitivity setting on / off start recording based on voice around
13. Vibration-Trigger - sensitivity setting on / off start recording based on the vibration around
14. Vibration Standby Mode - Adjustable speed "wake up" when detecting vibrations - can be set to "Hurry Up" or "Energy Saving"
15. Motion-Trigger Sensitivity - sensitivity setting on / off start recording based on motion in front of the camera
16. Auto On / Off - option to turn on "Auto mode" - the camera can start recording when car start / stop car / start recording when you started, and end at stopping car



- outside it is possible at this point to set times when the camera should record ("Scheduled Recording" - click on "Edit" to set the desired times
- desired times by mouse
- After labeling program prompts you to choose whether the camera is in the time to record all the time (Always record) or only on the basis of some of detection (Voice / vibration / movement)
- Right-click on the rule created in the table can be adjusted (Edit) or deleted (Delete)

spyshop Ko morate izvedeti



After completing all of these settings, you need to click on the "Sync Settings to DVR".

Higher mode MK96 (ZIR32) contains a wider thanks to extra equipment several options:

1. PIR-Trigger - On / Off PIR motion detection
2. *Ext Trigger In-Contact Type - set the type of contact input when connecting an external sensor*
3. *Ext-Trigger Out Contact Type - set the type of contact output when connecting an external sensor*

spyshop
ko morate izvedeti

3.4 Folder

1. Click this submenu to open the folder records.
2. Recordings from cameras located in the "ZETTA".
3. Recordings can be dragged into the PC and delete.

3.5 Format

1. This option can format the memory.
2. And delete all records.

4. Final provisions

We encourage you to pay attention to our products from categories ***Spy camera modules.***

Control of the device, depending on the individual series differ slightly.

Use the unit in accordance with applicable laws and regulations. The Contractor shall have no liability for the use of the instrument in contravention of these regulations.